

62831 U-WL-500

Blind actuator, FM, WL



1	Notes on the instruction manual	4
2	Trademarks	4
3	Safety	5
3.1	Information and symbols used	5
3.2	Intended use	6
3.3	Improper use	6
3.4	Target group / Qualifications of personnel.....	7
3.4.1	Operation	7
3.4.2	Installation, commissioning and maintenance	7
3.5	Cyber security	8
3.6	Safety instructions	14
4	Information on protection of the environment	15
4.1	Environment	15
5	Setup and function.....	16
5.1	Functions.....	16
6	Technical data	17
6.1	Technical data	17
6.2	Dimensional drawings	17
7	Connection and installation	18
7.1	Planning instructions	18
7.2	Safety instructions	19
7.3	Circuit diagrams	20
7.4	Requirements for the electrician.....	21
7.5	Mounting	22
7.6	Dismantling	22
8	Overview of applications.....	23
8.1	Expansion stage "Device control"	24
8.2	Expansion stage "Room control"	25
8.3	Expansion stage "Home automation"	26
8.4	Overview ABB-free@home® Next App areas	27
8.5	Overview of start screen.....	28
8.6	System integration	29
8.7	System requirements	30
8.7.1	System requirements: "Device control"	30
8.7.2	System requirements: "Room control"	31
8.7.3	System requirements "Home automation"	31
9	Commissioning.....	32
9.1	Downloading and installing the app.....	32
9.2	Identifying the device	33

9.3	Commissioning in the expansion stage "Device control"	33
9.4	Commissioning of the expansion stage "Room control"	36
9.5	Commissioning of the expansion stage "Home automation"	39
9.5.1	Authorizations	39
9.5.2	Coupling of wireless devices with the System Access Point	39
9.5.3	Add device	41
9.6	Commissioning by scanning the QR code"	45
10	Operation.....	48
10.1	Display elements	48
10.2	Overview of parameters	49
10.2.1	Overview of actuator parameters.....	50
10.2.2	Overview of sensor parameters	54
10.3	Individual operating functions	56
10.4	Automation/Timer	59
10.4.1	Automation/Timer settings	60
10.5	General settings	62
10.6	Settings / maintenance.....	63
10.7	Firmware update	64
10.8	Factory settings	64
11	Maintenance.....	65
12	Declaration of conformity	65
13	Index.....	66

1 Notes on the instruction manual

Please read through this manual carefully and observe the information it contains. This will assist you in preventing injuries and damage to property and ensure both reliable operation and a long service life for the device.

Please keep this manual in a safe place.

If you pass the device on, also include this manual along with it.

ABB accepts no liability for any failure to observe the instructions in this manual.

If you require additional information or have questions about the device, please contact ABB or visit our Internet site at:

<https://new.abb.com/en>

2 Trademarks

Die Wortmarke Bluetooth® und die Bluetooth®-Logos sind eingetragene Marken von Bluetooth SIG, Inc.. Jede Verwendung dieser Marken durch Busch-Jaeger Elektro GmbH erfolgt unter Lizenz. Andere Marken und Handelsnamen sind Eigentum ihrer jeweiligen Eigentümer.

3 Safety

The device has been constructed according to the latest valid regulations governing technology and is operationally reliable. It has been tested and left the factory in a technically safe and reliable state.

However, residual hazards remain. Read and adhere to the safety instructions to prevent hazards of this kind.

ABB accepts no liability for any failure to observe the safety instructions.

3.1 Information and symbols used

The following Instructions point to particular hazards involved in the use of the device or provide practical instructions:



Danger

Risk of death / serious damage to health

- The respective warning symbol in connection with the signal word "Danger" indicates an imminently threatening danger which leads to death or serious (irreversible) injuries.



Warning

Serious damage to health

- The respective warning symbol in connection with the signal word "Warning" indicates a threatening danger which can lead to death or serious (irreversible) injuries.



Caution

Damage to health

- The respective warning symbol in connection with the signal word "Caution" indicates a danger which can lead to minor (reversible) injuries.



Attention

Damage to property

- This symbol in connection with the signal word "Attention" indicates a situation which could cause damage to the product itself or to objects in its surroundings.



NOTE

This symbol in connection with the word "Note" indicates useful tips and recommendations for the efficient handling of the product.

The following safety symbols are used in the operating manual:



This symbol alerts to electric voltage.

3.2 Intended use

The device serves for the remote control of blind motors. Via the 230 V extension unit input conventional switches can be integrated.

They may be installed in dry interior rooms in flush-mounted boxes and additionally in ceiling boxes. If different types of installations are used, the applicable regulations are to be observed.

The device is intended for the following:

- Operation according to the listed technical data
- Installation in dry interior rooms and suitable flush-mounted boxes / ceiling boxes
- Use with the connecting options available on the device

The intended use also includes adherence to all specifications in this manual.

3.3 Improper use

Each use not listed in Chapter 3.2 “Intended use“ on page 6 is deemed improper use and can lead to personal injury and damage to property.

ABB is not liable for damages caused by use deemed contrary to the intended use of the device. The associated risk is borne exclusively by the user/operator.

The device is not intended for the following:

- Unauthorized structural changes
- Repairs
- Outdoor use
- The use in bathroom areas

3.4 Target group / Qualifications of personnel

3.4.1 Operation

No special qualifications are needed to operate the device.

3.4.2 Installation, commissioning and maintenance

Installation, commissioning and maintenance of the device must only be carried out by trained and properly qualified electrical installers.

The electrical installer must have read and understood the manual and follow the instructions provided.

The electrical installer must adhere to the valid national regulations in his/her country governing the installation, functional test, repair and maintenance of electrical products.

The electrical installer must be familiar with and correctly apply the "five safety rules" (DIN VDE 0105, EN 50110):

1. Disconnect
2. Secure against being re-connected
3. Ensure there is no voltage
4. Connect to earth and short-circuit
5. Cover or barricade adjacent live parts

3.5 Cyber security

The industry faces intensifying cyber security risks. In order to increase stability, safety and robustness of its solutions, ABB has formally established cyber security robustness testing as part of the product development process.

The following measures are prerequisite for the safe operation of your ABB-free@home® system.

Prevention of access to the different media

The careful isolation of the system against unauthorized access is the basis for every protective concept. In case of a ABB-free@home® system, it is only authorized persons (fitter, caretaker, user) who are allowed physical access to the ABB-free@home® system. During planning and installation the ABB-free@home® media (cable and wireless) and the critical points must be protected as best as possible.

Sub-distributions with ABB-free@home® devices are to be locked or located in rooms to which only authorized persons have access.

Bus cabling

- The cable ends of the ABB-free@home® Twisted Pair cable should not be visible or project out from the wall, neither inside nor outside the building.
- Bus lines in outdoor areas or in areas with limited protection represent an increased risk. Here the physical access to the ABB-free@home® Twisted Pair cable should be made exceptionally difficult.

IP cabling within the building

The local network represents a sensitive component for safe communication. That is why unauthorized access to the local network should be prevented. The normal security mechanisms for IP networks are to be used. These, for example, are:

- Safe encryption of wireless networks
- Use of complex passwords and protection of these against unauthorized persons
- Physical access to network interfaces (Ethernet interfaces) should only be possible in protected areas.
- MAC filter

Connection to the Internet

To prevent improper use, no router ports from the Internet into the home network are to be opened for ABB-free@home® components. A VPN tunnel or the MyBuildings portal is suitable for secure remote control.

Data protection

We take the protection of your personal data very seriously and adhere to the legally valid regulations regarding data protection. Personal data are obtained and processed only to the extent necessary for the operation of this online offer. The following declaration provides you with an overview of how we guarantee this protection and what type of data we record and for what purpose.

Personal data (also telemetry data)

Personal data consists of details regarding the personal or factual circumstances of a certain or identifiable natural person. Information that cannot be connected directly or indirectly to your identity, such as the number of users of a page, is not personal data.

In the case MyBuildings these consist of data you have made available to us yourself, such as registration data, contact data, or data added in connection with the services used, such as bank data, as well as data of devices which have been allocated to the user account.

The personal data you have made available to us within the scope of this online offer will be used exclusively for this purpose. Your personal data are not passed on to third parties if you do not expressly permit this or we are obligated to do so based on a law or decision of a court or public authority. An exception to this are order processors, whom we carefully select and contractually obligate to observe our instructions and to strictly adhere to the required technical and organisational measures for data protection.

Duration of storage and deletion

Your personal data will be deleted in accordance with the data protection law as soon as the purposes for the above-stated storage become inapplicable. However, a storage beyond the achievement of purpose can take place when we are obligated to do so on the basis of legal regulations. In this case, processing will be limited and the data will be deleted after the respective legal obligations have been abolished or been met.

Notice on privacy policies: <https://new.abb.com/privacy-policy/en>

Concrete handling of personal data that are obtained, stored and processed by the ABB-free@home® System Access Point 2.0:

Description	Processing options	Obtaining consent	Revocation of consent
User name (an alias or pseudonym)	The name of the user is entered in the app or in the web interface and used for the listing of possible users on the login screen.	The user must confirm the general business terms and conditions before the installation of the DUT and the app.	The user can revoke his agreement by resetting the DUT on the factory settings.
E-mail address of the user	An e-mail address (independent of the user!) can be entered in the app and the DUT to be able to be notified about a configured event (e.g. Failure of the heating system).	See "User name" These details are optional.	See "User name"
Local data (city, urban area) on the location of the test specimen	The DUT uses this information only locally. Application: Control of blinds depending on summer or winter season.	The user must confirm the general business terms and conditions before the installation of the DUT and the app.	See "User name" or simply delete the entry.
Location coordinates (lat/long) for the location of the DUT	The DUT uses this information to implement the application: Geofencing. Data are transmitted to the mobile app.	The user must confirm the general business terms and conditions before the installation of the test specimen and the app.	See "User name" or simply delete the entry.
Certificate that is used to authenticate the DUT by the Cloud service	DUT authentication at the Cloud service	The user must confirm the general business terms and conditions before the installation of the DUT and the app.	See "User name" or logout from Cloud service.

Table:1 Handling of obtained personal data



Notice

Further instructions are available in the corresponding chapter of this product manual or in the system manual for ABB-free@home®!

Concrete handling of telemetry data that are recorded, stored and processed by ABB-free@home® System Access Point 2.0:

The telemetry data include all sensors and actuators that are connected via the cable-bound or wireless interfaces with the SysAP. Also IP-connected devices that are controlled by the SysAP or from which it requests information, are enclosed (e.g. Philips HUE, Sonos loudspeakers, etc.). The telemetry data also include events at which a sensor sends data or an actuator receives control messages that changes its state, as well as data that are exchanged with IP-connected devices within the local network. The telemetry data also include information that was exchanged with the mobile app, and whether/when a user was logged into the SysAP, whether/when/which configurations were changed by whom.

Description	Purpose	Security check	Personal data
Local recording is supported	Can be shared with ABB R&D. R&D can verify protocols on the basis of: <ul style="list-style-type: none"> – Problems at the configuration – Competitive conditions between different devices/processes 	The user can exchange protocols with ABB but the automatic exchanged is not activated. <ul style="list-style-type: none"> – Can be used to detect brute-force-attacks 	N/A
Backup files (can be generated by the user)	Can be passed on to ABB to understand the structure of the system configuration and to support customers and R&D during the determination of causes of problems.	K.A. (The data are not used for the security check)	PersData-x (see the table at the top)
All telemetry data (data supplied by sensors and switching frequencies of actuators, etc.) are stored in the Cloud/IoT-Hub.	Foresighted maintenance: The target of ABB is to inform the customer when a product has reached the end of its service life or to notify the state the product is in. There is the option of recording operating hours and switching cycles.	Telemetry data are used to increase the security of the product by the recognition of anomalies. The anomalies could include several incorrect password entries within a short space of time. These telemetry data can be used to inform the user at the login via a dialogue that there was an attempt to find out your account / your PIN code / etc.	N/A

Table:2 Handling of the collected telemetry data



Notice

Further instructions are available in the corresponding chapter of this product manual or in the system manual for ABB-free@home®!

Secure Shell Protocol

The Secure Shell Protocol (SSH) is a cryptographic network protocol for the remote login and the secure operation of network services via an unsecured network.

This function can only be used by the ABB technician, not by the end customer.

The end customer always has his device under his own control. Without activation by the user/end customer, the interface cannot be used by anyone.

The interface is only intended for use in the local network with physical access to the device. The end customer should not set up port forwarding, VPN or similar, to make remote access possible.

The interface must only be activated when the respective ABB technician has identified himself with his personal ID and his employee ID.



Attention! - Access to the interface

ABB Technicians would never request this from the customer, especially not on the telephone! Every try to convince the customer to remotely access the interface, should be reported via cybersecurity@ch.abb.com.

To activate the Secure Shell Protocol, proceed as follows:

1. Log yourself into the System Access Point.



Fig. 1: ABB-free@home® Configuration

2. Select “ABB-free@home® configuration” via the main menu or the page menu in the user interface of the System Access Point.



Fig. 2: Activating the Secure Shell Protocol

3. Tap on the tile “free@home System Access Point” [1].
4. Tap on “Service” [2].
5. In section “Further settings” activate the checkbox “Activate SSH access” [3].

Certificate REST API

The Rest API makes it possible for developers to implement own scripts based on JAVA. Scripts that use the local REST interface can be signed via certificate. The System Access Point 2.0 offers the option to generate and download such a certificate.

This setting is an option that is only intended for developers. There are simple templates available. The corresponding developer documentation can via:

<https://developer.eu.mybuildings.abb.com/>

General deleting functions of ABB-free@home® System Access Point 2.0:

Description	Target group	Confirmation
<p>The user has the option to reset the DUT to the factory settings. In this case all configuration data that were created by the user or created as a result of the entries made available by the user, were deleted from the flash memory.</p> <p>All configuration data that were created in defined configuration files (XML documents), are deleted from the file system in the flash memory. Then new configuration files without content are created.</p>	User data and personal data on the device	After the successful reset to the factory settings the device is in the state of delivery.
The user can log the device out of the Cloud service.	Personal data about associated services	The status of the Cloud connection is "isolated".

Table:3 General deleting functions



Notice

Further instructions are available in the corresponding chapter of this product manual or in the system manual for ABB-free@home®!

Shut-down, archiving and destruction

If the device is to be taken out of operation, archived or destroyed, first remove all sensitive and personal data from the device with the function "Reset to factory settings" (see chapter "Settings / maintenance" on page 63).

3.6 Safety instructions



Danger - Electric voltage!

Electric voltage! Risk of death and fire due to electric voltage of 100 ... 240 V. Dangerous currents flow through the body when coming into direct or indirect contact with live components. This can result in electric shock, burns or even death.

- Work on the 100 ... 240 V supply system may only be performed by authorised and qualified electricians.
- Disconnect the mains power supply before installation / disassembly.
- Never use the device with damaged connecting cables.
- Do not open covers firmly bolted to the housing of the device.
- Use the device only in a technically faultless state.
- Do not make changes to or perform repairs on the device, on its components or its accessories.
- Keep the device away from water and wet surroundings.



Caution! - Risk of damaging the device due to external factors!

Moisture and contamination can damage the device.

- Protect the device against humidity, dirt and damage during transport, storage and operation.

4 Information on protection of the environment

4.1 Environment



Consider the protection of the environment!

Used electric and electronic devices must not be disposed of with domestic waste.

- The device contains valuable raw materials which can be recycled. Therefore, dispose of the device at the appropriate collecting depot.

All packaging materials and devices bear the markings and test seals for proper disposal. Always dispose of the packaging material and electric devices and their components via the authorized collecting depots and disposal companies.

The products meet the legal requirements, in particular the laws governing electronic and electrical devices and the REACH ordinance.

(EU Directive 2012/19/EU WEEE and 2011/65/EU RoHS)

(EU REACH ordinance and law for the implementation of the ordinance (EC) No.1907/2006).

5 Setup and function

5.1 Functions

The device serves for the remote control of blind motors. It can be operated as ABB flexTronics® wireless device. Also the integration into a ABB-free@home® wireless system is possible. The device can be combined with other participants of the ABB-free@home® system and also used for group functions, scenes or events.

Operation and setting is made via the ABB-free@home® Next App or the web-based surface of the System Access Point.

Via the 230 V extension unit inputs conventional switches can be integrated.




Fig. 3: Blind actuator, FM, WL

[A] Blind actuator, FM, WL

[B] Extension unit push-button (optional)

[C] PC, tablet or smartphone



Notice

Basic information about the integration into the ABB-free@home® system is contained in the system manual. It is available for downloading at www.abb.com/freathome.

Overheating protection

The device is equipped with an overheating protection.

- The device switches off automatically during longer operation with a high load in a hot environment.
- Switch the device back on after cooling down or the fault has been rectified.

6 Technical data

6.1 Technical data

Description		Value
Transmission protocol		– free@home flex – Bluetooth
Transmission frequency		2.4 - 2.48 GHz
Maximum transmission power	WL (wireless)	< 15 dBm
	Bluetooth LE (BLE)	< 10 dBm
Standby power consumption		0.3 W
Switched load line	Connection	230 V AC \pm 10%, 50/60 Hz
	Maximum load	4 A $\text{\textcircled{M}}$
	Clamps (screwless)	1.0 - 2.5 mm ²
	Skinning length	10 mm
Admissible cable length for extension operation:		100 m max.
Protection rating		IP20
Ambient temperature		-25°C ... +55°C
Storage temperature		-25 °C ... +70 °C

Table:4 Technical Data



Attention! - Damage to device

Risk of damaging the device due to overheating!

- When using transformers, ensure that each transformer is fused individually on the primary side or with a thermal fuse according to the manufacturer's specifications.

6.2 Dimensional drawings




Fig. 4: Dimensions (all dimensions are in mm)

7 Connection and installation

7.1 Planning instructions

**Note**

Transmitter and receiver communicate via radio control. The transmission range depends on the structural conditions. Walls and ceilings, especially steel reinforcements or metal claddings, reduce the transmission range. The distance of components to each other and to other transmitters that also emit high-frequency signals (e.g. computers, audio and video systems) should be at least 1 m.

**Note**

Planning and application instructions for the system are available in system manual for ABB-free@home®. This can be downloaded via www.abb.com/freethome.

7.2 Safety instructions



Danger - Electric shock due to short-circuit!

Risk of death due to electrical voltage of 100 to 240 V during short-circuit in the low-voltage line.

- Low-voltage and 100 - 240 V lines must not be installed together in a flush-mounted box!
- Observe the spatial division during installation (> 10 mm) of SELV electric circuits to other electric circuits.
- If the minimum distance is insufficient, use electronic boxes and insulating tubes.
- Observe the correct polarity.
- Observe the relevant standards.



Danger - Electric voltage!


Install the device only if you have the necessary electrical engineering knowledge and experience.

- Incorrect installation endangers your life and that of the users of the electrical system.
- Incorrect installation can cause serious damage to property, e.g. due to fire.

The minimum necessary expert knowledge and requirements for the installation are as follows:


- Apply the "five safety rules" (DIN VDE 0105, EN 50110):
 1. Disconnect
 2. Secure against being re-connected
 3. Ensure there is no voltage
 4. Connect to earth and short-circuit
 5. Cover or barricade adjacent live parts.
- Use suitable personal protective clothing.
- Use only suitable tools and measuring devices.
- Check the type of supply network (TN system, IT system, TT system) to secure the following power supply conditions (classic connection to ground, protective earthing, necessary additional measures, etc.).
- Observe the correct polarity.

7.3 Circuit diagrams



- L External conductor
- N Neutral conductor
- ↑1 Motor output 1 = "Down"
- ↑2 Motor output 2 = "Up"

Fig. 5: Electrical connection 62831 U-WL-500



- L External conductor
- N Neutral conductor
- ↑1 Motor output 1 = "Down"
- ↑2 Motor output 2 = "Up"
- ↓C1 Extension unit input 1 "Down"
- ↓C2 Extension unit input 2 = "Up"

Fig. 6: Electrical connection 62831 U-WL-500 with extension unit



Notice

For the connection of two motors a cut-off relay must be installed!

7.4 Requirements for the electrician



Danger - Electric voltage!

Install the device only if you have the necessary electrical engineering knowledge and experience.

- Incorrect installation endangers your life and that of the user of the electrical system.
- Incorrect installation can cause serious damage to property, e.g. due to fire.

The minimum necessary expert knowledge and requirements for the installation are as follows:

- Apply the "five safety rules" (DIN VDE 0105, EN 50110):
 1. Disconnect
 2. Secure against being re-connected
 3. Ensure there is no voltage
 4. Connect to earth and short-circuit
 5. Cover or barricade adjacent live parts.
- Use suitable personal protective clothing.
- Use only suitable tools and measuring devices.
- Check the type of supply network (TN system, IT system, TT system) to secure the following power supply conditions (classic connection to ground, protective earthing, necessary additional measures, etc.).

7.5 Mounting



Notice

The device can be mounted in a ceiling box or flush-mounted box such as behind a socket outlet or a switch. Check beforehand whether there is sufficient space.

To install the device, perform the following steps:

1. If necessary, remove the already installed flush-mounted insert, (e.g light switch).
2. Connect the cables to the terminal block.
 - Observe correct wiring (see chapter 7.3 “Circuit diagrams“ on page 20).




Fig. 7: Mounting in the flush-mounted box

3. Set the device into the flush-mounted box.
4. Then again mount the previously demounted flush-mounted insert or cover of the flush-mounted box.

7.6 Dismantling

Dismantling is carried out in the reverse order to mounting.

8 Overview of applications

The device can be used in three different expansion stages:

- Device Control (individual control)
 - The operation in this expansion stage takes place as with a conventional blind actuator. The device can additionally be controlled and parameterised with the ABB-free@home® Next App.
 - For more detailed information, see chapter “Expansion stage "Device control"” on page 24.
- Room Control
 - In this expansion stage the remote control and parameter setting of a blind actuator and additional devices are made with the ABB-free@home® Next App via Bluetooth®.
 - The expansion stage allows the migration of the device configuration in a home automation with ABB-free@home®.
 - For more detailed information, see chapter “Expansion stage "Room control"” on page 25.
- Home automation
 - In this expansion stage the remote control is made with the ABB-free@home® Next App. The parameter setting is made in the web-based interface of the System Access Point of a ABB-free@home®-configuration.
 - For more detailed information, see chapter “ Expansion stage "Home automation"” on page 26.

Change between expansion stages

If the device was configured within the "Room control" expansion stage, it can also be migrated in a home automation with ABB-free@home®. The parameter setting is retained.

The change of the "Device control" expansion stage into the "Room control" expansion stage or into a home automation is only possible after a previous reset and a following reconfiguration of the device.

8.1 Expansion stage "Device control"

This expansion stage contains only one device and no other devices or links. The device can be controlled and parameterised with the ABB-free@home® Next App. The operation is made as with a conventional blind actuator.

- The access from the smartphone to the networked device is carried out with Bluetooth via the ABB-free@home® Next App.
- The remote control and parameter setting is carried out via the ABB-free@home® Next App.




Fig. 8: Device control expansion stage (individual control)

8.2 Expansion stage "Room control"

In this expansion stage the configuration, remote control and parameter setting of a blind actuator and additional devices are made with the ABB-free@home® Next App.

- Up to 32 devices can be linked with each other in the expansion stage via a mesh network.
- The devices can be linked with each other and controlled with group functions, scenes and timers.
- The access from the smartphone to the networked devices is carried out with Bluetooth via the ABB-free@home® Next App.
- A registration at MyBuildings is necessary. Here the configuration data are stored.
- No System Access Point is necessary.





Fig. 9: Room control expansion stage


8.4 Overview ABB-free@home® Next App areas

In the following you see an example of the function and operating areas of the app for the device.


Overview area (Example)



Parameters (Example)



General settings Others (example)




- Change of device name and the position
- Switching of loads
- Setting the device parameters
- Information about the device and maintenance
- Display of the software version of the device
- Reset device to factory settings

8.5 Overview of start screen

	<p>[A] Three-point menu The switch menu opens by tapping on the three-point menu (views within illustrations A1 and A2). – Here you can move the curtain via the sliding switch / switch [A1]. – You can also open the function "Lock to position" via the toothed-wheel. It can be used to lock the curtain permanently in the position (top or bottom).</p>
	<p>[B] Adding device By tapping the arrow, the drop-down menu for adding an additional device opens (see the detailed view in the illustration [B1]).</p>
	<p>[C] Hamburger menu Tapping on the Hamburger menu opens the function overview of the ABB-free@home® Next App (see the detailed view in the illustration [C1]).</p>
	<p>[1] Name of the selected installation.</p>
	<p>[2] Name of the currently selected device within the selected installation.</p>
	<p>[3] Switching The actuator can be moved and stopped by tapping the icon.</p>
	<p>[4] Home button Back to start page of the device.</p>
	<p>[5] Automation / Timer For additional information, please see chapter "Automation/Timer".</p>
	<p>[6] Signal strength Bluetooth signal strength of the currently selected device.</p>

Table. 5: Overview of start screen



[A1]	Sliding switch / switch for moving the curtain.
[A2]	Detail view of function "Lock at position."
[B1]	Detailed view of the drop-down menu for adding an additional device.
[C1]	Detailed view of the function overview of the ABB-free@home® Next App.

Table. 6: Overview of start screen - detailed view

8.6 System integration

The device can be integrated in ABB-free@home®.

Networking with other devices in the app ABB-free@home® Next App is possible. Depending on the desired expansion stage, additional steps are required.

- Registration at MyBuildings.
- Room control: Additional ABB-free@home® flex devices for the setup of a mesh network are necessary.
- Home automation: For integration in ABB-free@home® installation with a System Access Point.

System limits

- **Bluetooth®:**
 - The radio range between the devices amounts to a maximum of 10 meters.
 - A Bluetooth® connection is used for the connection between the smartphone and an additional device. If thick walls are located within the planned radio line, the attainable transmission ranges are greatly reduced.
 - The same applies to connections on other floors. In this case the radio signals must pass through the floor ceilings.
- **Wireless 2.4 GHz:**
 - The radio range between the devices amounts to a maximum of 30 meters.
 - If thick walls are located within the planned radio line, the attainable transmission ranges are greatly reduced.
 - The same applies to connections on other floors. In this case the radio signals must pass through the floor ceilings.

8.7 System requirements

The system requirements differ in dependence of the selected expansion stage. The system requirements are available in the following sections.

- Expansion stage "Device control"
 - Information about the expansion stage: Chapter 8.1 "Expansion stage "Device control"" on page 24
 - System requirements: Chapter 8.7.1 "System requirements: "Device control"" on page 30
- Expansion stage "Room control"
 - Information about the expansion stage: Chapter 8.2 "Expansion stage "Room control"" on page 25
 - System requirements: Chapter 8.7.2 "System requirements: "Room control"" on page 31
- Expansion stage "Home automation"
 - Information about the expansion stage: Chapter 8.3 "Expansion stage "Home automation"" on page 26
 - System requirements: Chapter 8.7.3 "System requirements "Home automation"" on page 31

8.7.1 System requirements: "Device control"

A mobile terminal device is required for commissioning in the expansion stage "Device control" via the ABB-free@home® Next App app .

In the following the designation "Smartphone" is used representatively.

Prerequisites:

- The current version of the app ABB-free@home® Next App is installed on your smartphone, at least however, version 2.4
- The smartphone has a Bluetooth function.
- The device is located in the radio range of the smartphone.
- The device is connected to the power supply.
- The ABB-free@home® Next App can be downloaded free of charge from the Apple App Store and from Google Play (see chapter "Downloading and installing the app" on page 32).

8.7.2 System requirements: "Room control"

A mobile terminal device is required for commissioning in the expansion stage "Room control" via the app ABB-free@home® Next App. In the expansion stage "Room control" the entire project (including device data and timers) can be stored within MyBuildings.

In the following the designation "Smartphone" is used representatively.

Prerequisites:

- The current version of the app ABB-free@home® Next App is installed on your smartphone, at least however, version 2.4.
- The smartphone has a Bluetooth function.
- The device is located in the radio range of the smartphone.
- The device is connected to the power supply.
- There are at least two or more devices available that can be networked with each other.
- The smartphone has a connection with MyBuildings.
- The ABB-free@home® Next App app can be downloaded free of charge from the Apple App Store and from Google Play (see see chapter "Downloading and installing the app" on page 32).

8.7.3 System requirements "Home automation"

For commissioning in the expansion stage "Home automation" via the app ABB-free@home® Next App and the web-based interface of the System Access Point, a mobile terminal device (smartphone, tablet, etc.) or a computer is required.

Prerequisites:

- A functioning network (WLAN or LAN) is available with the System Access Point.
- There is an available ABB-free@home® configuration.
- The current Firmware version is installed on the System Access Point, at least however, version 3.4.0.
- The smartphone has a connection to System Access Point.
- The current version of the app ABB-free@home® Next App is installed on your smartphone, at least however, version 2.4.
- The device is in the radio range of the System Access Point or an additional ABB-free@home® wireless device.
- The device is connected to the power supply.
- The ABB-free@home® Next App can be downloaded free of charge from the Apple App Store and from Google Play (see chapter "Downloading and installing the app" on page 32).

9 Commissioning



Notice

- After being activated, the device is in programming mode and is automatically visible in the app or in the System Access Point for 30 minutes.
- As long as the device is in programming mode, the LED on the device flashes.



Notice

A device that has already been logged in must be reset to enable it to be set again into programming mode.

- The device can be reset via the ABB-free@home® Next App app. (see chapter “Settings / maintenance“ on page 63/ Chapter 10.8 “Factory settings“ on page 64).

The possible procedures for commissioning are described in the following. Depending on the expansion stage selected, the individual commissioning steps vary.

- Commissioning in the expansion stage "Device control"
 - Chapter 9.3 “Commissioning in the expansion stage "Device control"“ on page 33
- Commissioning in the expansion stage "Room control"
 - Chapter 9.4 “Commissioning of the expansion stage "Room control"“ on page 36
- Commissioning in the expansion stage "Home automation"
 - Chapter 9.5 “Commissioning of the expansion stage "Home automation"“ on page 39

You can also scan a non-programmed device via the supplied QR code and then make it operational.

- Chapter 9.6 “Commissioning by scanning the QR code“ on page 45

9.1 Downloading and installing the app

Download the app ABB-free@home® Next App from the respective store and install it on your smartphone.



Android



IOS

9.2 Identifying the device

Before commissioning, the device can be identified in the ABB-free@home® Next App for 30 minutes after a voltage reset. This function is especially helpful when several device are made operational at the same time.

To identify a device, proceed as follows:

1. Open the Burger menu and select "Manage Bluetooth devices".
2. Select the desired device.
3. Tap on "Identify".
 - The LED on the device and the connected load flash five times.

9.3 Commissioning in the expansion stage "Device control"

To connect the device with the app, proceed as follows.

1. Activate the Bluetooth on your smartphone and connect the device to the power supply.




Fig. 11: Integrating the device [A] - [C] (example illustration)

2. Open the app ABB-free@home® Next App and tap on the plus icon [A].
3. Select "Add a new Bluetooth device" and confirm with "Continue" [B].
4. Tap on "Continue" to add the device via Bluetooth [C].

As alternative, you can add the device by scanning the QR code (see Chapter 9.6 "Commissioning by scanning the QR code" on page 45).




Fig. 12: Integrating the device [D] - [F] (example illustration)

5. Select "New installation" when there is none yet [D].
 - Select the desired installation type and confirm with "Continue" [E].
 - Assign a name for the new installation and select "Continue".
 - Assign a password for the new installation and confirm with "Continue".



Notice

If already available, an existing installation can be used.

6. Assign a new device name and position the device inside the installation with the help of the plus icon (specification of floor and room). Then confirm the settings with "Continue" [F].
 - The device is added to the installation [G].




Fig. 13: Integrating the device [G] - [H] (example illustration)

7. The app indicates that the device was added successfully to the installation [H]. Complete the process via "Finished" or, if necessary, repeat the steps via the option "Add an additional device".

The device is connected with the app ABB-free@home® Next App and can be configured via the parameters (see chapter "Overview of parameters" on page 49).

9.4 Commissioning of the expansion stage "Room control"

To connect the device with the app, proceed as follows.

1. Activate the Bluetooth on your smartphone and connect the device to the power supply.




Fig. 14: Integrating the device [A] - [C] (example illustration)

2. Open the app ABB-free@home® Next App and tap on the plus icon [A].
3. Select "Add a new Bluetooth device" and confirm with "Continue" [B].
4. Tap on "Continue " to add the device via Bluetooth [C].

As alternative, you can add the device by scanning the QR code (see chapter "Commissioning by scanning the QR code" on page 45).




Fig. 15: Integrating the device [D] - [F] (example illustration)

5. Select "New installation" when there is none yet [D].
 - Select the desired installation type and confirm with "Continue" [E].
 - Register yourself at MyBuildings [F].
 - Assign a name for the new installation and select "Continue".
 - Assign a password for the new installation and confirm with "Continue".



Notice

If already available, an existing installation can be used.




Fig. 16: Integrating the device [G] - [H] (example illustration)

6. Assign a new device name and position the device inside the installation with the help of the plus icon (specification of floor and room). Then confirm the settings with "Continue" [G].
 - The device is added to the installation [H].
7. The app indicates that the device was added successfully to the installation [I]. Complete the process via "Finished" or, if necessary, repeat the steps via the option "Add an additional device".

The device is connected with the app ABB-free@home[®] Next App and can be configured via the parameters (see chapter "Overview of parameters" on page 49).

9.5 Commissioning of the expansion stage "Home automation"



Notice

- It is assumed that the basic commissioning steps of the overall system have already been carried out.
- Knowledge about the basic functions of the app and the System Access Point is assumed.

9.5.1 Authorizations

To be able to make settings on the system during commissioning, the login of the fitter is necessary.



Notice

Detailed information on user management is available in the ABB-free@home® system manual.



Notice

The setting options and illustrations described in this chapter assume a login as fitter in the web-based user interface of the System Access Point. The ABB-free@home® Next App can also be used as alternative.

9.5.2 Coupling of wireless devices with the System Access Point

ABB-free@home® Wireless devices must first be coupled with the System Access Point before they can be used in a project. The devices exchange a security key during the coupling process (free@home® wireless key).

Communication between devices is carried out encrypted after coupling and they cannot be connected with another System Access Point. They must first be reset to the factory settings.

Carry out the following steps to integrate one or several devices into the system:

1. Install the ABB-free@home® wireless devices.
2. Use your smartphone, tablet or PC to call up the user interface of the System Access Point that is ready for use.
3. Switch on the mains power supply of the ABB-free@home® wireless devices.
 - The devices are now in programming mode for 30 minutes.



free@home configuration
Integrate & configure your free@home system

Fig. 17: ABB-free@home® Configuration

4. Select "ABB-free@home® configuration" via the main menu or the page menu in the user interface of the System Access Point.




Fig. 18: Coupling wireless devices with the System Access Point

5. Tap on the "Search for devices" button and then on the "Search" button in the "Search for wireless devices" window.
 - Close the notification window "Search for wireless devices" by clicking on "OK".
 - The System Access Point consecutively scans all ABB-free@home[®] wireless devices. Devices that are in programming mode are automatically integrated into the system. The search process in the System Access Point ends 10 minutes after the last device has been found.
 - Integrated devices are listed in the user interface in submenu "Devices, scenes and groups".
 - To abort the search, click on "End search".
6. Use the serial numbers to check whether all installed devices have been found. If a device has not been found, reset it to the factory settings and start a new scanning process.

Possible reasons for not finding devices:

- The device is not in programming mode.
- The 30-minute programming time has expired.
- The device has already been coupled with a different system.



Notice

Bluetooth[®] is deactivated after the device has been programmed via the System Access Point.

9.5.3 Add device



Fig. 19: Devices, scenes and groups

1. Select "Devices, scenes & groups" via the main menu or the page menu in the user interface of the System Access Point.
 - The "Building plan" opens.



Fig. 20: Opening the building plan and list of components (example illustration)

2. Tap on the round plus icon [1] at the bottom right.
 - The menu "Select component" opens.
3. Tap on the desired characteristic in the list of components.
 - The menu with the available devices, functions and actuators opens.




Fig. 21: Pulling the device out of the menu bar (example illustration)

4. Select the desired device and pull it into the building plan via drag-and-drop.

- If you pull a new device into a room via drag-and-drop, a pop-up window opens in which all devices that are located in the system and which have not been allocated to a room. The devices are suitable respectively for the selected application (e.g. all blind actuators, if the blind application has been selected).




Fig. 22: Pop-up window with the suitable devices (example illustration)

5. Select the corresponding channel.

The device can be identified via the serial number or via switching.




Fig. 23: Allocation of devices

A window opens which lists all the devices suitable for the application selected.

Identification via serial number




Fig. 24: Identification via serial number

- Compare the serial number and the short ID of the identification label printed on the device with the numbers and IDs in the list. This is how the searched for device and possibly the searched for channel are identified.
The specifications of the identification label should also be transmitted to the device plan.



Notice

The DMC code on the device can be optionally scanned with the app. This contains a configuration PIN. At a configuration change with a different app or tool, then also the DMC must be scanned in addition to the local connection via NFC. This serves for the protection against unauthorized reconfiguration.

Identification via switching

If several devices are listed in the device list, you can identify them by switching the actual device.




Fig. 25: Identification via switching (example illustration)

1. Open the device list.
2. Press the "Identification" button [1] and then switch the actual device.
 - Or, as alternative, press only the button [2] in the web interface.
 - The connected load is switched.
 - The device is then selected automatically in the device list.

Assigning a name




Fig. 26: Assigning a name (example illustration)

3. Enter a name that is easy to understand and under which the application is to be displayed later, e.g. "South-wall weather station".
4. Tap on the "Save" button to take over the adjustments.
 - This takes over the entry.

9.6 Commissioning by scanning the QR code"



Notice

- The QR code is located on the rear side of the device.
- This method can also be used if the device is not connected to the power supply. However, one needs to be near the device with the system after the power is connected to add the device automatically.




Fig. 27: Integrating the device [A] - [C] (example illustration)

1. Tap the plus icon [A].
2. Select "Add a new Bluetooth device" [B] and confirm with "Continue".
3. Tap on "Scan QR code" [C].
4. Use the camera of your smartphone to scan the printed QR code on the rear side of the device.



Notice

To be able to scan the QR code via the app ABB-free@home® Next App , you must allow access to the camera when you are requested.




Fig. 28: Integrating the device [D] - [F] (example illustration)

5. Select "New installation" when there is none yet [D].
 - Select the desired installation type and confirm with "Continue" [E].
 - Assign a name for the new installation and select "Continue".
 - Assign a password for the new installation and confirm with "Continue".



Notice

If already available, an existing installation can be used.

6. Assign a new device name and position the device inside the installation with the help of the plus icon (specification of floor and room). Then confirm the settings with "Continue" [F].
 - The device is added to the installation [G].




Fig. 29: Integrating the device [G] - [H] (example illustration)

7. The app indicates that the device was added successfully to the installation [H]. Complete the process via "Finished" or, if necessary, repeat the steps via the option "Add an additional device".

When the device is activated, it can be configured via the parameters (see chapter "Overview of parameters" on page 49).

10 Operation

10.1 Display elements




Fig. 30: Display elements

[A] LED Status

LED Status	Description
5 flashes	The device flashes five times because the function “Identify” was activated.
Flashing	The device is in programming mode.

Table. 7: Conditions of status LED

10.2 Overview of parameters

For the configuration of the parameters, select the installation and the desired device. Then scroll down to the parameters.

The overview shows the individual parameters in their sequence of appearance during operation.



Notice

Some changes must, if necessary, be saved via the "Save" button for them to become effective.




Fig. 31: Parameters section (example illustration)



Notice

In the description of parameters, the preselected standard values are underlined. These standard values are used when neither a value is entered nor a setting is made.

10.2.1 Overview of actuator parameters

Channel name	
Here an individual name can be assigned to the channel.	
Function	
The function of the actuator is selected already during the calibration of the device. However, it can be changed later if necessary.	
<u>Blind actuator</u>	For controlling of motorized blinds.
Roller blind actuator	For controlling of motorized roller blinds.
Roof window actuator	For controlling of motorized roof windows.
Awning actuator	For controlling of motorized awnings.

Parameters of function “Blind actuator”

Operating mode	
<u>Moving with a long press</u>	The curtain moves continuously up/down at a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a brief press of a button. At a brief press of the button the curtain moves one step up/ down or turns the slats by one position.
Moving with a brief press	The curtain moves continuously up/down at a brief press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a long press of a button. At a long press of the button the curtain moves one step up/ down or turns the slats by one position.
Moving/stopping with a long press	The curtain moves continuously up/down at a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped by releasing after a further long press of the opposite button. At a brief press of the button the curtain moves one step up/ down or turns the slats by one position.
Moving at brief and long operation	The curtain moves to the top / bottom both at a brief as well as a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a brief or long press of a button. This operating mode is suited only for curtains without slats.
Total duration of slats movement [ms]	
0 ... 10,000 ms	Setting the time in which the slats require for a complete change in direction of their angle. The value can be set in milliseconds via the sliding controller or by entry in the text field. The time for an individual step is fixed at 200 ms and cannot be changed.
Total time of downward movement [s]	
3 ... 600 s	Setting the movement time via the sliding controller or by entry in the text field. Step size: 1 s

Total time of upward movement [s]	
3 ... 600 s	Setting the movement time of the curtain to the top end position via the sliding controller or by entry in the text field. Step size: 1 s
Motor pause time [ms]	
0 ... 1,800 ms	The time in which the motor does not move after activation can be set via the sliding controller or input in the text field. Step size: 10 ms See the correct motor idle time in the operating manual of the motor.
Behaviour during malfunction	
Parameters cannot be changed	
<u>No reaction</u>	There is no reaction when a fault occurs.
Raising	The curtain is moved to the top position when a fault occurs.
Lowering	The curtain is moved to the bottom position when a fault occurs.
Stop and no further action	When the curtain is being moved during a fault, it is stopped.
Behaviour at cancelling of alarms	
Here the behaviour of the curtain can be selected when the alarm message of the alarm transmitter is no longer pending.	
<u>Remain on the position</u>	The curtain remains in the position that was taken when the alarm was triggered.
Back to position	The curtain goes back to the original position that was taken when the alarm was triggered.

Parameters of function “Roller blind actuator” / “Roof window actuator” / “Awning actuator”

Operating mode	
<u>Moving with a long press</u>	The curtain moves continuously up/down at a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a brief press of a button. At a brief press of the button the curtain moves one step up/ down or turns the slats by one position.
Moving with a brief press	The curtain moves continuously up/down at a brief press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a long press of a button. At a long press of the button the curtain moves one step up/ down or turns the slats by one position.
Moving/stopping with a long press	The curtain moves continuously up/down at a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped by releasing after a further long press of the opposite button. At a brief press of the button the curtain moves one step up/ down or turns the slats by one position.
Moving at brief and long operation	The curtain moves to the top / bottom both at a brief as well as a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a brief or long press of a button. This operating mode is suited only for curtains without slats.
Total time of downward movement [s]	
3 ... 600 s	Setting the movement time via the sliding controller or by entry in the text field. Step size: 1 s
Total time of upward movement [s]	
3 ... 600 s	Setting the movement time of the curtain to the top end position via the sliding controller or by entry in the text field. Step size: 1 s
Motor pause time [ms]	
0 ... 1,800 ms	The time in which the motor does not move after activation can be set via the sliding controller or input in the text field. Step size: 10 ms See the correct motor idle time in the operating manual of the motor.
Behaviour during malfunction	
Parameters cannot be changed	
<u>No reaction</u>	There is no reaction when a fault occurs.
Raising	The curtain is moved to the top position when a fault occurs.
Lowering	The curtain is moved to the bottom position when a fault occurs.
Stop and no further action	When the curtain is being moved during a fault, it is stopped.

Behaviour at cancelling of alarms

Here the behaviour of the curtain can be selected when the alarm message of the alarm transmitter is no longer pending.

<u>Remain on the position</u>	The curtain remains in the position that was taken when the alarm was triggered.
Back to position	The curtain goes back to the original position that was taken when the alarm was triggered.

10.2.2 Overview of sensor parameters



Notice

The device is an actuator. On the extension unit input a conventional button can be wired and configured here. Also the connection of a Sub-insert flex is possible.

Channel name	
Here an individual name can be assigned to the channel.	
Block local operation	
Yes	With this function the operation can be deactivated via the button. Operation is then only possible via the app.
No	Local operation is possible.
Function	
<u>Disable blind</u>	The blind is moved into the "Top" or "Bottom" state and locked against any further operation. After cancelling the forced control, the blind returns to its original state.
Roller blind operation	This function serves for the normal operation of a roller blind or blind. The curtain can be moved to the top or bottom as well as stopped. If slats are available, they can be turned.

Parameters of function "Block blind"

Disable blind	
<u>Force-position top</u>	The blind is moved into the to top end position and disabled against any further operation. The behaviour of the cancellation of forced control depends on parameter "Behaviour at cancelling of alarms".
Force-position bottom	The blind is moved into the to bottom end position and disabled against any further operation. The behaviour of the cancellation of forced control depends on parameter "Behaviour at cancelling of alarms".
Contact type	
Here the contact type for the extension unit is selected.	
<u>Normally open contact</u>	The contact is closed by actuating the switch.
Normally closed contact	The contact opens when a the switch is actuated.

Parameters of function “Roller blind operation”

Operating mode	
<u>Moving with a long press</u>	<p>The curtain moves continuously up/down at a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a brief press of a button.</p> <p>At a brief press of the button the curtain moves one step up/ down or turns the slats by one position.</p>
Moving with a brief press	<p>The curtain moves continuously up/down at a brief press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a long press of a button.</p> <p>At a long press of the button the curtain moves one step up/ down or turns the slats by one position.</p>
Moving/stopping with a long press	<p>The curtain moves continuously up/down at a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped by releasing after a further long press of the opposite button.</p> <p>At a brief press of the button the curtain moves one step up/ down or turns the slats by one position.</p>
Moving at brief and long operation	<p>The curtain moves to the top / bottom both at a brief as well as a long press of the button and remains in the top/bottom position. The movement of the curtain can be stopped with a brief or long press of a button.</p> <p>This operating mode is suited only for curtains without slats.</p>
Contact type	
Here the contact type for the extension unit is selected.	
<u>Normally open contact</u>	The contact is closed by actuating the switch.
Normally closed contact	The contact opens when a the switch is actuated.

10.3 Individual operating functions

Calibration

Blind actuators are used for numerous applications. They can, for example, control a motorized roof window or an awning. The device can be optimized for one of these applications via the function "Calibration".

The necessary values such as the total "Up", "Down" movement times, the adjustment times of the slats and the time of the motor are determined with the calibration.




Fig. 32: Calibration

1. Tap on "Calibrate" [A], to start the calibration.
2. Select the desired application [B].
 - Now perform the instructions step by step on the screen.
3. Tap on "Save" [C], to take over the determined values.
 - Calibration is complete.

Links

Sensors and actuators can be linked with each other. This allows simple On/Off circuits or two-way circuits to be implemented.

Under the "Links", you can create, delete or edit links. In addition, you can see for which devices a link has been created. A difference is made between links of channels and scenes.

- A list opens when tapping the plus icon in front of the channel or scene.
- Create the desired link in the list by tapping the desired device. A successful link is indicated with a tick.
- The link can be deleted again by tapping on the dustbin icon.



Notice

Sensor and actuator are already linked during commissioning.

Reaction during events

The behaviour during the occurrence of different events such as alarms or opening/tilting a window depends on the selected function of the blind actuator.

If several events occur at the same time, the behaviour responds to the event with the highest priority.

Event	Priority	Behaviour at selected function			
		Roller blind actuator	Blind actuator	Roof window actuator	Awning actuator
Force-position ON (by action)	1	Selectable (up / down)			
Force-position OFF (by action)	-	Back to position			
Wind alarm ON	2	Move up and lock	Move up and lock	Close and lock (∨) ¹	Retract and lock (∧) ²
Wind alarm OFF	-	Selectable ³ ("Remain on position" or "Return to last position")			
Frost alarm ON	4	Move and block	Move and block	Close and lock (∨) ¹	Retract and lock (∧) ²
Frost alarm OFF	-	Selectable ³ ("Remain on position" or "Return to last position")			
Rain alarm ON	5	Move down and lock	Move up and lock	Close and lock (∨) ¹	Retract and lock (∧) ²
Rain alarm OFF	-	Selectable ³ ("Remain on position" or "Return to last position")			

Table 8: Events of blind actuator

¹ Icon "Arrow down" on rocker

² Icon "Arrow up" on rocker

³ The behaviour at cancelling of alarms is specified per channel in the parameter settings of the actuator and is valid for all alarm types.

When using a ABB-free@home[®] window contact, additional subsequent events occur.

Event	Priority	Behaviour at selected function	
		Roller blind actuator	Blind actuator
Windows tilted	3	During movement in any direction, move to the top and block. Without movement, block immediately.	
Window is open	3	During movement in any direction, move to the top and block. Without movement, block immediately.	
Window closed	-	Retain position	

Table 9: Events of window contact

10.4 Automation/Timer



Notice


The device is not equipped with batteries.

- Time programs are stopped at a power failure.
- The time in the device is synchronized again only at the next connection with the app.

Up to 28 switching times can be programmed via the automation. Each timer has a weekday function and can be programmed for one or several weekdays.


In the following you see the function and operating areas of the "Automation" app area.

Automation overview area



- Display of the number of configured timers
- Display of the defined switching times
- Activation / deactivation of timers

**Automation
Creation of a new timer**



- Specification of the type (specified time, Astro-dependent)
- Specification of repetition for weekdays
- Activation of live mode
- Specifying the position

Notice: The available settings are dependent on the selected function of the actuator.



Notice

Timers can be created both for the device as well as the switching output (channel). For example, a timer can be created to block the device for a specific time.

10.4.1 Automation/Timer settings

Different switching times can be programmed in the automation area.

The following overview shows the setting options and parameters in their sequence of appearance during operation.



Notice

Performed changes must, if necessary, be saved via the "Save" button for them to become effective.



Notice

The respective standard values in the overview are underlined. These standard values are used when neither a value is entered nor a setting is made.




Fig. 33: Automation Settings

Start at	
<u>Specified time</u>	The timer starts at a previously specified time.
xx.xx after sunrise	Astro timer, at which the starting time to a fixed offset is relative to the sunrise. <ul style="list-style-type: none"> ▪ Astro function, 00:00 to 23:50
xx.xx after sunset	Astro timer, at which the starting time to a fixed offset is relative to the sunset. <ul style="list-style-type: none"> ▪ Astro function, 00:00 to 23:50
At the earliest	Specifying the earliest time at which the astro timer is to start.
At the latest	Specifying the latest time at which the astro timer is to start.

Repetition on every	
Mon/Tue/Wed/Thu/Fri/Sat/Sun	Specifying the weekdays at which the timer is to repeat itself.
<u>Switching on all weekdays</u>	The standard setting. The timer switches on all weekdays at the same time.

Live mode	
On	If the live-mode is activated, at the change of the configuration the actuator changes into the timer settings to display the configured switching state.
<u>Off</u>	If the live-mode is deactivated, the configuration in the timer settings has temporarily no effect on the actuator. Only when the timer triggers is the actuator switched into the configured switching state.

Positions	
Here the position of the blind can be set that is to be moved to at the specified time.	
Blind position	The desired position of the blind can be selected by shifting.
Slat position	The desired position of the slats can be set with the slider.

Continuously locked	
<u>Continuous switching deactivated (set status)</u>	With this function an active continuous switching is ended and the selected switching state (ON/OFF) is stopped.
Continuous switching deactivated (last status)	With this function an active continuous switching is ended and the last switching state of the actuator is stopped.
Permanently switched on	With this function the device is blocked for the time command and switched on.
Permanently off	With this function the device is blocked and switched off.

10.5 General settings

The name of the device can be changed in the "General settings" and the position (floor/room) inside the house can be defined.



General settings Expansion stage Device control	General settings Expansion stage Room control and Home automation
	

Table. 10: General settings

10.6 Settings / maintenance



Settings / maintenance Expansion stage Device control	Settings / maintenance Expansion stage Room control and Home automation
	
<p>Information about the device [1] Overview of the device data</p> <p>Maintenance [2] Setting and changing device password [3] Rebooting the device [4] Read device in again [5] Resetting the device</p>	<p>Parameters [1] Channel selection</p> <p>Information about the device [2] Overview of the device data</p> <p>Maintenance [3] Rebooting the device [4] Read device in again [5] Resetting the device</p>

Fig. 34: Other - Settings / Maintenance



Notice

The channel selection (1-4 channels, standard channel 1) can be used to make different parameter settings individually for each device channel.

- Aside from the manual selection in the app, the "Timer" can be used to change time-dependent between the channels (and therefore between the function characteristics).

10.7 Firmware update

The ABB-free@home® Next App on the start page shows the notification "Device update available" when a new firmware is available for your device.

To perform the update, proceed as follows:

1. Under the notice "Device update available" tap on "Update now".
2. In the next window, tap on "Update".
 - The update starts and a progress bar indicates the progress.
 - After the update is concluded, the device restarts.
 - The message "Update successful" appears in the app.



Notice

In the expansion stages Device control and Room control, a connection via Bluetooth® to the device is necessary.

10.8 Factory settings

The device can be reset via the "Reset device" function (see chapter "Settings / maintenance" on page 63).

When the installation, with which the device is linked, is no longer available in the ABB-free@home® Next App, the device can only be reset by a master reset.

To perform a master reset, proceed as follows:

1. Perform a voltage reset on the device.
 - The device can now be reset for 5 minutes with a master reset.
2. Open the Burger menu and select "Manage Bluetooth devices".
3. Select the desired device.
4. Tap on "Rest".
 - The requirements of the master reset are sent to the device.
 - A further voltage reset must be performed for the confirmation.
 - The device will be reset to the factory settings and is now in programming mode.
 - If desired, the device can then be reconnected with the app.

11 Maintenance

Check the device from time to time for software updates to guarantee the stability and the compatibility of the system.

In addition, the device is maintenance-free. In case of damage, e.g. during transport or storage, do not perform repairs. Once the device is opened, the warranty is void.

Access to the device must be guaranteed for operation, testing, inspection, maintenance and repairs (according to DIN VDE 0100-520).

12 Declaration of conformity

ABB herewith declares, that radio system type 62831 U-WL-500 conforms to directive 2014/53/EU.

The complete text of the EU Declaration of Conformity is available at the following Internet address:

62831 U-WL-500	https://new.abb.com/products/2CKA006710A0041
----------------	---

Table:11 Link to Declaration of Conformity

13 Index

A	
Add device.....	41
Assigning a name	44
Authorizations.....	39
Automation/Timer	28, 59
Automation/Timer settings	60
C	
Circuit diagrams	20, 22
Commissioning	32
"Scanning the QR code"	32, 33, 36, 45
Expansion stage\.....	32, 33
Commissioning of the expansion stage	
"Home automation"	32, 39
"Room control"	32, 36
Connection and installation.....	18
Coupling of wireless devices.....	39
D	
Dimensional drawings.....	17
Dismantling.....	22
Display elements	48
Downloading and installing the app	30, 31, 32
E	
Environment	15
Expansion stage	
Device control	23, 24, 30
Home automation	23, 26, 30
Room control.....	23, 25, 30
F	
Factory settings.....	32, 64
Firmware update	64
Functions.....	16
G	
General settings	62
I	
Identification	43
Identification label	43
Improper use.....	6
Individual operating functions	56
Information and symbols used	5
Information on protection of the environment.....	15
Intended use	6
M	
Maintenance	65
Mounting	22
N	
Notes on the instruction manual	4
O	
Operation	7, 48
Overview of actuator parameters	50
Overview of applications	23
Overview of parameters	35, 38, 47, 49
Overview of sensor parameters	54
Overview of start screen.....	28
P	
Planning instructions.....	18
Q	
Qualification of personnel.....	7
R	
Requirements for the electrician	21
S	
Safety	5
Safety instructions	14, 19
Serial number	43
Settings / maintenance	13, 32, 63, 64
Setup and function	16
System access Point	26
System integration.....	29
System requirements	30
"Device control"	30
"Home automation"	30, 31
"Room control".....	30, 31
T	
Target group	7
Technical data	17
Trademarks.....	4



Busch-Jaeger Elektro GmbH
A member of the ABB Group

Freisenbergstraße 2
D-58513 Lüdenscheid, Germany

<https://new.abb.com/en>

Customer service:
Tel.: +49 2351 956-1600