

Gooseneck Microphone

IP FLUSH MASTER STATION



Installing the Gooseneck Microphone

The Gooseneck Microphone (part no. 1008097500) is available for the IP Flush Master Station.

To install the Gooseneck Microphone:

1. Remove the cover plug from the opening for the microphone on the front panel.
2. Thread the microphone cable through the opening, the lock washer and nut.
3. Tighten the nut on the microphone's threaded stud.
4. Insert the microphone's IDC socket into the upper two pins of the 3-pin header (**J7**) located at the lower left side of the station. The signal wire (**white**) should be on the top pin while the ground wire (**green**) should be on the bottom pin.
5. Slide the S1 switch (bottom back of station) to **EXT** to activate the external microphone function.

